

**Step 1**  
Lay back assembly on the floor  
Attach the side frames with (4) 2 1/4" bolts  
Do not tighten bolts yet fig.1

**Step 2**  
Insert (2) pins into pre-drilled holes  
on the back assembly. fig.1

**Step 3**  
Set bench upright. First, attach the front  
part of the seat using (2) 2 1/4" bolts. fig.2

**Step 4**  
Push the rear part of the seat up into  
the pins located on the back assembly.  
Attach the rear of the seat using  
(2) 2 1/4" bolts. fig. 2

Tighten all bolts at this time

- (2) Sideframe
- (1) Seat
- (1) Back
- (1) Hardware pack

**TOOLS NEEDED**

4mm HEX KEY: INCLUDED



Qty.	Description
2	A - Pin
8	B - 2 1/4" bolt

