



Step 1

Attach the seat to the sideframes using (6) 1 1/2" bolts - Do not tighten bolts yet

Step 2

Attach the back assembly *bottom* to the seat using (2) 1 1/2" bolts

Then attach the back assembly *top* to the sideframes using (2) 3/4" bolts

* Tighten all bolts at this time

- (2) Sideframes
- (1) Seat
- (1) Back
- (1) Hardware pack

TOOLS NEEDED

Phillips head screwdriver or 4mm hex key: Included

Qty.	Description
8	A - 1 1/2" Bolt
2	B - 3/4" Bolt

ALL BOLTS ARE 1/4-20