



1. ATTACH "J" END SUPPORTS TO RACK ASSEMBLY USING 4 - 3 1/2" BOLTS.
2. ATTACH 119" WHEEL STOP, FOOTER DOWN, TO "J" END SUPPORTS USING 4 - 2" BOLTS..
3. SQUARE AND TIGHTEN ALL HARDWARE
4. IF ANCHORING IS REQUIRED, ANCHOR AS SPECIFIED. ANCHORS NOT PROVIDED

ITEM	QTY	PART NO.	DESCRIPTION
1	4	200410	"J" END SUPPORT
2	1	200414	119" RACK ASSEMBLY
3	2	200417	119" WHEEL STOP
4	4	200235	3 1/2" X 5/16" HEX HEAD CAP SCREW
5	4	200236	2" x 5/16" HEX HEAD CAP SCREW
6	8	200233	5/16" SERRATED FLANGE NUT
7			