



1. ATTACH "J" AND "L" END SUPPORTS TO RACK ASSEMBLY USING 4 - 3 1/2" BOLTS.
2. ATTACH 119" WHEEL STOP, FOOTER DOWN, TO "J" END SUPPORTS USING 2 - 2" BOLTS.
3. SQUARE AND TIGHTEN ALL HARDWARE
4. IF ANCHORING IS REQUIRED, ANCHOR AS SPECIFIED. ANCHORS NOT PROVIDED

ITEM	QTY	PART NO.	DESCRIPTION
1	2	200410	"J" END SUPPORT
2	1	200414	119" RACK ASSEMBLY
3	1	200417	119" WHEEL STOP
4	4	200235	3 1/2" X 5/16" HEX HEAD CAP SCREW
5	2	200236	2" X 5/16" HEX HEAD CAP SCREW
6	6	200233	5/16" SERRATED FLANGE NUT
7	2	200411	"L" END SUPPORT