


- Step 1**
Attach the seat assembly to the sideframes using (4) 3" chair screws in pre-drilled holes
Note: notches in seat face front
 - Step 2**
Attach the back assembly to the sideframes using (4) 3" chair screws in pre-drilled holes
 - Step 3**
Attach the front and rear braces to the sideframes using (4) 3" chair screws in pre-drilled holes
 - Step 4**
Attach rocker bottoms to the sideframes using (4) 3" chair screws in pre-drilled holes
- * Tighten all bolts at this time

- (2) Sideframe
- (2) Rocker bottom
- (1) Seat
- (1) Back
- (2) Brace
- (2) Finials
- (1) Hardware pack

TOOLS NEEDED
4mm HEX KEY: INCLUDED



Qty.	Description
------	-------------

16	A - 3" CHAIR SCREW
----	--------------------